

Electric Single Motor



STAND UP
desk store

CODE ISSUE TROUBLESHOOTING SOLUTION

HOT	Motor is Overheated	Overheating typically occurs after more than two minutes of continuous use. Unplug the power cable for at least five minutes, then reconnect the power cable
HOT	Desk Isn't Raising Or Lowering Properly	Make sure the desk is plugged in and all the cables are properly connected. Then try using the keypad to raise and lower the desk.
HOT	Desk Still Isn't Working	If the desk is still not working, unplug the desk for a minimum of three minutes. This will reset the electronics. Reconnect the power, then try raising and lowering the desk.